R

T D-6 K

Electronic Percussion Kit

The TD-6K kit arrives as Roland's most affordable compact drum system, bringing the world's leading drum sounds and acclaimed playability to a new price point. This expandable set is based around the all-new TD-6 Percussion Sound Module, newly developed rubber drum pads, and new dual-trigger cymbal pads with choke capabilities, giving you the power to sound and play your best.

Features:

Affordable new compact drum system based around TD-6 Percussion Sound Module and new drum and cymbal pads.
TD-6 Percussion Sound Module offers 64-voice polyphony, 1,024 high-quality drum sounds, 262 backing sounds, 99 kits and a 6-part sequencer.
Five PD-6 8.5" rubber pads provide durable, reliable triggering.
Two CY-6 12" dual-trigger cymbal pads yield natural dynamics and "choke" capabilities.
9 trigger inputs on TD-6 accommodate up to 11 pads and cymbals, including acclaimed Roland mesh-head V-pads Includes hi-hat pedal, kick drum trigger, stand and all connecting hardware.
TD-6 module and complete system designed for easy setup and intuitive operation.

- **Initialize**

This function restores the pad and instrument settings, song data and other settings back to their original factory state:

1. Whilst holding [SHIFT], press [EDIT(SETUP)].
2. Press [>] to select "Factory Reset."
3. Press [ENTER]
4. Press [INC/+] or [DEC/-] to select "ALL."
5. Press [ENTER]

- **Play The Demo Song**

This function lets you listen to the onboard demo songs.

1. Whilst holding down [KIT], press [SONG]
2. Press [INC/+] or [DEC/-] to select the song
3. Press [PLAY >] to listen to the song
4. Press [STOP] to end the song
5. Press [KIT] to exit the demo mode

- **Choosing a Drum Kit**

The TD-6 comes with 99 preset drum kits. Now's probably a good time for you to try them out:

1. Press [KIT]
2. Press [INC/+] or [DEC/-] to select the drum kit you require.
3. Bash away!!!

- **Playing Along with Songs**

The TD-6 features a sequencer that can record and playback accompaniment tracks:

1. Press [SONG]
2. Press [INC/+] or [DEC/-] to select the song you require.
3. Press [PLAY >] for the song to begin playback and [STOP] for it to finish.
4. Play along to the backing!

- **Muting the Drum Backing**

If the pre-programmed drums are doing your head in, you can mute them:

1. Press [SONG]
2. Press [INC/+] or [DEC/-] to select the song you require.
3. Press [PART MUTE] to mute the programmed drums.
4. Press [PLAY >] for the song to begin playback and [STOP] for it to finish.
5. Play along to the backing!

- **Adjusting the Tempo**

You can adjust the tempo of the pre-programmed song while playback is in progress:

1. Whilst holding down [SHIFT], press [CLICK (TEMPO)]
2. Press [INC/+] or [DEC/-] to select the desired tempo.
3. Press [EXIT] to finish the procedure.